

2 Delivery

2.1 RECEIPT

Inspect the crate and make note of any physical damage. If severe damage is present, then consideration should be given to rejecting the shipment and contacting the shipping company concerning in-transit damage claims. **REXA** makes every effort to properly package the product so that it is shipped and received without damage.

2.2 STORAGE

If the actuators and control enclosure are not immediately installed, provisions for storage must be made. The equipment should not be removed from the original containers. The ambient environment must be:

- ✓ **Clean**—no airborne particles or contaminants
- ✓ **Non Corrosive**—minute quantities of gases can concentrate in a confined area
- ✓ **Dry**—relative humidity must be sufficiently low to prevent moisture condensation on chilled metal components
- ✓ **Temperature**—recommended storage temperature is between 10°F (–12°C) and 120°F (50°C)



2.3 UNPACKING

The **REXA Mpac** actuator is shipped completely filled with oil and ready to be installed. It has been operated, tested and thoroughly inspected. After removing the actuator from the packaging, inspect it for any signs of mechanical damage that may have occurred during shipping. Immediately report any damage to the factory.

Compare the contents to the packing list included with every shipment. Immediately report any discrepancies to the factory.